

XP-002159446

AN - 1983-18991K [08]  
AP - JP19810107326 19810709  
CPY - KAOS  
DC - E34 F06  
DR - 1718-U  
FS - CPI  
IC - C11D7/08 ; D06L1/12  
MC - E31-C F03-J F03-J03  
M3 - [01] A111 A940 C017 C100 C108 C730 C801 C803 C804 C805 C807 M411 M781  
M903 M910 Q261 Q322 R023  
PA - (KAOS ) KAO CORP  
PN - JP58008180 A 19830118 DW198308 005pp  
- JP60024859B B 19850614 DW198528 000pp  
PR - JP19810107326 19810709  
XA - C1983-018510  
XIC - C11D-007/08 ; D06L-001/12  
AB - J58008180 Hospital clothes are washed with a soln. (in)organic acid at  
40-60 deg.C for 5-10 mins., followed by a cleaning soln. contg. sodium  
hypochlorite.  
- Pref. acid soln. is an aq. soln. of phosphoric acid of pH 2.5-4. Opt.  
detergent, e.g. soap and synthetic surfactant, and alkali, e.g. sodium  
methsilicate are added to the cleaning soln.  
- The cleaning is pref. done at 50-80 deg.C and pH 10-12 for 10-30  
mins., using 0-5 wt.% detergent, 0.05-0.2 wt.% alkali and 0.05-0.2  
wt.% sodium hypochlorite with effective chlorine content of 5-6%.  
- White garments, surgical gowns, bed sheets and bedding stained with  
blood, disinfectant, etc. are cleaned effectively.  
IW - CLEAN HOSPITAL CLOTHING WASHING SOLUTION ORGANIC ACID DEGREE MINUTE  
SODIUM HYPOCHLORITE CONTAIN SOLUTION  
IKW - CLEAN HOSPITAL CLOTHING WASHING SOLUTION ORGANIC ACID DEGREE MINUTE  
SODIUM HYPOCHLORITE CONTAIN SOLUTION  
NC - 001  
OPD - 1981-07-09  
ORD - 1983-01-18  
PAW - (KAOS ) KAO CORP  
TI - Cleaning hospital clothes - by washing in soln. of (in)organic acid at  
40-60 degrees C for 5-10 minutes, then with sodium hypochlorite-contg.  
soln.