

XP-002159446

AN - 1983-18991K [08]

AP - JP19810107326 19810709

CPY - KAOS

DC - E34 F06

DR - 1718-U

FS - CPI

IC - C11D7/08 ; D06L1/12

MC - E31-C F03-J F03-J03

M3 - [01] A111 A940 C017 C100 C108 C730 C801 C803 C804 C805 C807 M411 M781

M903 M910 Q261 Q322 R023

PA - (KAOS) KAO CORP

PN - JP58008180 A 19830118 DW198308 005pp

- JP60024859B B 19850614 DW198528 000pp

PR - JP19810107326 19810709

XA - C1983-018510

XIC - C11D-007/08 ; D06L-001/12

AB - J58008180 Hospital clothes are washed with a soln. (in)organic acid at 40-60 deg.C for 5-10 mins., followed by a cleaning soln. contg. sodium hypochlorite.

- Pref. acid soln. is an aq. soln. of phosphoric acid of pH 2.5-4. Opt. detergent, e.g. soap and synthetic surfactant, and alkali, e.g. sodium methsilicate are added to the cleaning soln.

- The cleaning is pref. done at 50-80 deg.C and pH 10-12 for 10-30 mins., using 0-5 wt.% detergent, 0.05-0.2 wt.% alkali and 0.05-0.2 wt.% sodium hypochlorite with effective chlorine content of 5-6%.

- White garments, surgical gowns, bed sheets and bedding stained with blood, disinfectant, etc. are cleaned effectively.

IW - CLEAN HOSPITAL CLOTHING WASHING SOLUTION ORGANIC ACID DEGREE MINUTE
SODIUM HYPOCHLORITE CONTAIN SOLUTION

IKW - CLEAN HOSPITAL CLOTHING WASHING SOLUTION ORGANIC ACID DEGREE MINUTE
SODIUM HYPOCHLORITE CONTAIN SOLUTION

NC - 001

OPD - 1981-07-09

ORD - 1983-01-18

PAW - (KAOS) KAO CORP

TI - Cleaning hospital clothes - by washing in soln. of (in)organic acid at 40-60 degrees C for 5-10 minutes, then with sodium hypochlorite-contg. soln.